

APPLICATOR PARTS LIST

TYPE HINGEBAR .250 FASTON FLAG

AMP AMP Incorporated
Harrisburg, PA 17105-3608

NO.	DESCRIPTION	REQ.	PART NO.	NO.	DESCRIPTION	REQ.	PART NO.	CRIMPING DATA			TERMINALS	
1	▲ WIRE CRIMPER	1	473070-1	42	FRONT STAB.BAR	1	811006-1	TO APPLY TERMINAL			63577	
2	▲ INS. CRIMPER	1	473128	43	-	-	-				-	
3	▲ ANVIL	1	810152-1	44	HINGE BLOCK & STAB.	1	810974-1	WIRE SIZE	CRIMP HEIGHT	-	-	
4	▲ ANVIL INSERT	1	811046-1	45	HINGE PIN	1	811007-1	22	-	-	-	
5	▲ SHEAR BLADE	1	853852-1	46	-	-	-	20	.056	-	-	
6	▲ REAR SHEAR PLATE	1	853860-1	47	HINGE BAR ASSEMBLY	1	565062-1	18	.058	-	-	
7	▲ SHEAR BLADE SPRING	1	810410-1	48	HINGE BAR SPRING	2	3-23846-5	16	.061	-	-	
8	▲ FRONT SHEAR PLATE	1	388632-3	49	STRIP GUIDE STOP	2	853851-1	-	-	-	-	
9	REAR ANVIL SPACER PL	-	-	50	STRIP HOLD DOWN	1	810411	CRIMP	SIZE	TYPE	FEED	
10	FRONT ANVIL SPACER PL	-	-	51	SPACER-COMP. SPRING	2	811070-1	WIRE	.140	TAB	-	
11	TOOL SPACER	-	-	52	CAM FOLLOWER HOLDER	1	810409	INSUL.	.140	0	.650	
12	CRIMP SPACER	-	-	53	CAM FOLLOWER	1	24746-1	SLEEVED	-	-	-	
13	FRONT STRIP GUIDE	1	811052-9	54	SPRING BRACKET	1	810418	INSULATION RANGE		WIRE RANGE		
14	REAR STRIP GUIDE	1	388621	55	▲ CAM FOLLOWER SPRING	1	810408	.070-.130		GA 22-16		
				56	HOOK HOLDER	1	810419	EXPLODED VIEW				
15	RAM	1	473828	57	▲ SHEAR PICK-UP HOOK	1	810416	A-6004-3, -4				
16	RAM RETAINER PLATE	1	465004-2	58	HOLD DOWN-HINGE BAR	1	811009-1	REMARKS:				
17	ADJ. PLATE	1	811010-1	59	DEPRESSOR SCREW	1	810642-1	▲ RECOMMENDED SPARE PARTS				
18	PROTECTIVE PLUG	1	23141-1	60	WASHER	4	376482	-				
19	APPLICATOR MOUNT ASSY.	-	-	61	▲ FEED FINGER SPRING	1	810421-1	-				
20	BASE PLATE	1	465238-1	62	PIN, DOWEL	1	1-21030-5	-				
21	BASE BLOCK	-	-	63	MICRO SWITCH	1	23496-1	-				
22	STRIP GUIDE PLATE	-	-	64	COVER, MICRO SWITCH	1	22689-2	-				
23	▲ ANVIL HOLDER	1	810423	65	BRACKET, MICRO SWITCH	1	811074-1	-				
24	AUX. ANVIL HOLDER	-	-	MISCELLANEOUS				-				
25	STRIPPER	-	-	66	CONNECTOR	1	22787-2	-				
26	STRIPPER MOUNT	-	-	67	SCREW, HOOK HOLDER	1	810413	-				
27	RETAINER PLATE	-	-	68	-	-	-	-				
28	STRIPPER MOUNT BRACKET	-	-	69	SPACER, ANVIL HOLDER	1	811223-1	-				
29	STRIPPER BUSHING	-	-	70	LEAD WIRE	1	465918-1	-				
30	STOCK DRAG	1	811063-4	71	PIN, DOWEL	1	465702-1	-				
31	STOCK DRAG HANDLE	-	-	72	-	-	-	-				
32	STOCK DRAG STUD	-	-	THIS APPLICATOR IS TO BE USED ON								
33	STOCK DRAG SPRING	2	810135	AMP-O-LECTRIC 1-471273-3								
34	STOCK DRAG ADJ. SCREW	-	-	-								
35	FEED FINGER HOLDER	1	810131	SERIAL NO.			DATE SHIPPED			DR. 1-15-91 C. MOYER		
36	FEED FINGER	1	810422	CUSTOMER NAME AND ADDRESS								
37	▲ FEED FINGER TIP	1	810420	CHK'D <i>Moyle/m</i>								
LOC A	38 FEED FINGER STUD	1	810414-1	APP'D <i>Moyle/m</i>								
	39 BASE CASTING	1	570238									
DIST 4	40 GUARD ASSEMBLY	1	457698-4									
	41 -	-	-									
				P	F	L	T	REVISION RECORD		APP	DATE	
				A				LOG NO	853787-1		SHEET 1 OF 1	REV 0