



**LK204-25**  
**Technical Manual**

**Revision: 2.0**


# Contents

<b>Contents</b>	<b>ii</b>
<b>1 Getting Started</b>	<b>1</b>
1.1 Display Options Available . . . . .	1
1.2 Accessories . . . . .	2
1.3 Features . . . . .	6
1.4 Connecting to a PC . . . . .	7
1.5 Installing the Software . . . . .	8
1.5.1 uProject . . . . .	8
<b>2 Hardware Information</b>	<b>9</b>
2.1 DB-9 Connector . . . . .	9
2.1.1 Power Through DB-9 Jumper . . . . .	10
2.2 Power/Data Connector . . . . .	10
2.3 Protocol Select Jumpers . . . . .	11
2.4 General Purpose Outputs . . . . .	12
2.5 Dallas 1-Wire Bridge . . . . .	13
2.6 Manual Override . . . . .	13
2.7 Keypad Interface Connector . . . . .	14
<b>3 Troubleshooting</b>	<b>15</b>
3.1 The display does not turn on when power is applied. . . . .	15
3.2 The display module is not communicating. . . . .	16
3.3 The display module is communicating, however text cannot be displayed. . . . .	16
<b>4 Communications</b>	<b>16</b>
4.1 Introduction . . . . .	16
4.1.1 I <sup>2</sup> C Communication . . . . .	16
4.1.2 Serial Communication . . . . .	17
4.2 Changing the I <sup>2</sup> C Slave Address . . . . .	17
4.3 Changing the Baud Rate . . . . .	18
4.4 Setting a Non-Standard Baud Rate . . . . .	18
<b>5 Text</b>	<b>20</b>
5.1 Introduction . . . . .	20
5.1.1 Character Set . . . . .	20
5.1.2 Control Characters . . . . .	21
5.2 Auto Scroll On . . . . .	21
5.3 Auto Scroll Off . . . . .	21
5.4 Clear Screen . . . . .	21
5.5 Changing the Startup Screen . . . . .	22
5.6 Set Auto Line Wrap On . . . . .	22
5.7 Set Auto Line Wrap Off . . . . .	23
5.8 Set Cursor Position . . . . .	23

5.9	Go Home . . . . .	24
5.10	Move Cursor Back . . . . .	24
5.11	Move Cursor Forward . . . . .	24
5.12	Underline Cursor On . . . . .	25
5.13	Underline Cursor Off . . . . .	25
5.14	Blinking Block Cursor On . . . . .	25
5.15	Blinking Block Cursor Off . . . . .	25
<b>6</b>	<b>Special Characters</b>	<b>26</b>
6.1	Introduction . . . . .	26
6.2	Creating a Custom Character . . . . .	26
6.3	Saving Custom Characters . . . . .	27
6.4	Loading Custom Characters . . . . .	28
6.5	Save Startup Screen Custom Characters . . . . .	28
6.6	Initialize Medium Number . . . . .	29
6.7	Place Medium Numbers . . . . .	29
6.8	Initialize Large Numbers . . . . .	30
6.9	Place Large Number . . . . .	30
6.10	Initialize Horizontal Bar . . . . .	31
6.11	Place Horizontal Bar Graph . . . . .	31
6.12	Initialize Narrow Vertical Bar . . . . .	32
6.13	Initialize Wide Vertical Bar . . . . .	32
6.14	Place Vertical Bar . . . . .	32
<b>7</b>	<b>General Purpose Output</b>	<b>33</b>
7.1	Introduction . . . . .	33
7.2	General Purpose Output Off . . . . .	33
7.3	General Purpose Output On . . . . .	34
7.4	Set Startup GPO state . . . . .	34
<b>8</b>	<b>Dallas 1-Wire</b>	<b>35</b>
8.1	Introduction . . . . .	35
8.2	Search for a 1-Wire Device . . . . .	35
8.3	Dallas 1-Wire Transaction . . . . .	36
<b>9</b>	<b>Keypad</b>	<b>37</b>
9.1	Introduction . . . . .	37
9.2	Auto Transmit Key Presses On . . . . .	38
9.3	Auto Transmit Key Presses Off . . . . .	38
9.4	Poll Key Press . . . . .	38
9.5	Clear Key Buffer . . . . .	39
9.6	Set Debounce Time . . . . .	39
9.7	Set Auto Repeat Mode . . . . .	40
9.8	Auto Repeat Mode Off . . . . .	41
9.9	Assign Keypad Codes . . . . .	41

<b>10 Display Functions</b>	<b>42</b>
10.1 Introduction . . . . .	42
10.2 Display On . . . . .	42
10.3 Display Off . . . . .	43
10.4 Set Brightness . . . . .	43
10.5 Set and Save Brightness . . . . .	43
10.6 Set Contrast . . . . .	44
10.7 Set and Save Contrast . . . . .	44
<b>11 Data Security</b>	<b>45</b>
11.1 Introduction . . . . .	45
11.2 Set Remember . . . . .	45
11.3 Data Lock . . . . .	46
11.4 Set and Save Data Lock . . . . .	47
<b>12 Miscellaneous</b>	<b>48</b>
12.1 Introduction . . . . .	48
12.2 Read Version Number . . . . .	48
12.3 Read Module Type . . . . .	49
<b>13 Command Summary</b>	<b>49</b>
13.1 Communications . . . . .	49
13.2 Text . . . . .	50
13.3 Special Characters . . . . .	51
13.4 General Purpose Output . . . . .	52
13.5 Dallas 1-Wire . . . . .	53
13.6 Keypad . . . . .	53
13.7 Display Functions . . . . .	54
13.8 Data Security . . . . .	55
13.9 Miscellaneous . . . . .	55
13.10Command By Number . . . . .	55
<b>14 Appendix</b>	<b>57</b>
14.1 Specifications . . . . .	57
14.1.1 Environmental . . . . .	57
14.1.2 Electrical . . . . .	57
14.2 Optical Characteristics . . . . .	58
14.3 Physical Layout . . . . .	59
14.4 Definitions . . . . .	60
14.5 Contacting Matrix Orbital . . . . .	60

# 1 Getting Started



The LK204-25 is an intelligent LCD display designed to decrease development time by providing an instant solution to any project. With the ability to communicate via serial RS-232/TTL and I<sup>2</sup>C protocols, the versatile LK204-25 can be used with virtually any controller. The ease of use is further enhanced by an intuitive command structure to allow display settings such as backlight brightness, contrast and baud rate to be software controlled. Additionally, up to thirty-two custom characters such as character sets for bar graphs, medium and large numbers may be stored in the non-volatile memory to be easily recalled and displayed at any time.

## 1.1 Display Options Available

The LK204-25 comes in a wide variety of colors including the standard yellow/green or inverse yellow, the popular blue/white and the crisp white/grey as well as inverse red which is excellent for viewing at night. Extended voltage, and temperature options are also available, to allow you to select the display which will best fit your project needs.




Figure 1: LK204-25 Options

## 1.2 Accessories

---

**NOTE** Matrix Orbital provides all the interface accessories needed to get your display up and running. You will find these accessories and others on our e-commerce website at <http://www.matrixorbital.com>. To contact a sales associate see Section 14.5 on page 60 for contact information.

---



Figure 2: 5V Power Cable Adapter



Figure 3: 12V Power Cable Adapter (V/VPT Models)



Figure 4: Breadboard Cable




Figure 5: Serial Cable 4FT




Figure 6: Communication and 5V Power Cable




Figure 7: Aluminum Mountings





Figure 8: Keypad Mountings




Figure 9: Mounting Kits



Figure 10: 4X4 Keypad

## 1.3 Features


- 20 column by 4 line alphanumeric liquid crystal display
- Selectable communication protocol, RS-232 or I<sup>2</sup>C
- One-wire interface
- Six, 5V -20mA, general purpose outputs for a variety of applications
- Lightning fast communication speeds, up to 57.6 kbps for RS-232 and 400 kbps for I<sup>2</sup>C
- Default 19.2 kbps serial communication speed
- Extended temperature available for extreme environments of -20C to 70C
- Extended voltage and efficient power supply available
- Built in font with provision for up to 8 user defined characters
- Use of up to 127 modules on the same 2 wire I<sup>2</sup>C interface
- 1-wire bus that is capable of communicating with up to 32 devices over a single bus
- Fully buffered so that no delays in transmission are ever necessary
- Ability to add a customized splash / startup screen
- Software controlled contrast and brightness with configurable time-out setting up to 90 minutes
- Use of up to a 25 key keypad with a 10 key buffer
- Horizontal or vertical bar graphs
- Extended temperature option
- Fits Matrix Orbital's mountings without any modifications

## 1.4 Connecting to a PC

The LK204-25 connects seamlessly to a PC and it is an excellent means of testing the functionality. To connect your display to a PC, you will require a standard RS-232 9-pin serial cable such as the one pictured in *figure 5 on page 3*, as well as a modified 5V power adapter such as the one pictured in *figure 2 on page 2*.

In order to connect your display to a personal computer follow these easy instructions:

1. Plug the serial cable into the com port you wish to use.
2. Connect the modified 5V power adapter to a power lead from your PC power supply (you will have to open your computer case).
3. Connect the serial cable to the DB-9 connector on the back of the display.
4. Connect the 5V power adapter to the 4-pin connector on the back of the display.



---

**WARNING** DO NOT use the standard floppy drive power connector, as this will not provide you with the correct voltage and will damage the display module.




Figure 11: PC vs Matrix Orbital Display Module Wiring

## 1.5 Installing the Software


### 1.5.1 uProject

uProject was designed by Matrix Orbital to provide a simple and easy to use interface that will allow you to test all of the features of our alpha numeric displays.

To install uProject from the Matrix Orbital CD, follow the following steps:

1. Insert the Matrix Orbital CD-ROM into the CD drive
2. Locate the file, *uProject.exe*, which should be in the “CD-drive:\Download” directory.
3. Copy *uProject.exe* to a directory that you wish to run it from.
4. Double click on "uProject.exe"

Be sure to check the information selected in the COM Setup the first time uProject is run. Once this information is entered correctly the program can be used to control all functions of the graphic display.



<b>Comport</b>	The serial port the display is plugged in to.
<b>Baudrate</b>	The communication speed the display module is set to. (Default 19,200)

Figure 12: uProject Settings


---

#### NOTES

- uProject and other alphanumeric software may also be downloaded from Matrix Orbital's support site at [http://www.matrixorbital.ca/software/software\\_alpha/](http://www.matrixorbital.ca/software/software_alpha/)
-

## 2 Hardware Information

Refer to the following diagram for this chapter:




- |                            |                           |
|----------------------------|---------------------------|
| 1 DB-9 Connector           | 5 Power / Data Connector  |
| 2 Power Through DB9 Jumper | 6 Keypad Interface        |
| 3 GPOs                     | 7 Protocol Select Jumpers |
| 4 Manual Override          | 8 Dallas 1-Wire Bridge    |

Figure 13: LK204-25

### 2.1 DB-9 Connector

The LK204-25 provides a *DB-9 Connector* to readily interface with serial devices which use the EIA232 standard signal levels of  $\pm 12V$  to  $\pm 12V$ . It is also possible to communicate at TTL levels of 0 to +5V by setting the *Protocol Select Jumpers* to TTL. As an added feature it is also possible to apply power through pin 9 of the *DB-9 Connector* in order to reduce cable clutter. However, in order to accomplish this you must set the *Power Through DB-9 Jumper*.



- Pin 2** Rx \ SCL (I<sup>2</sup>C clock)
- Pin 3** Tx \ SDA (I<sup>2</sup>C data)
- Pin 5** GND
- Pin 9** PWR (*Must solder Power Through DB-9 Jumper. See table 1 on the next page for power requirements.*)

Figure 14: RS-232 Pin out

### 2.1.1 Power Through DB-9 Jumper

In order to provide power through pin 9 of the *DB-9 Connector* you must place a solder jumper on the *Power through DB-9 Jumper* pictured in **figure 15** below. The LK204-25 allows all voltage models to use the power through DB-9 option, see table 1 on the following page for display module voltage requirements.




Figure 15: Power Through DB-9 Jumper



**WARNING** Do not apply voltage through pin 9 of the DB-9 connector AND through the Power/Data Connector at the same time.

## 2.2 Power/Data Connector

The *Power/Data Connector* provides a standard connector for powering the display module. The LK204-25 requires five volts for the standard display module, between nine to fifteen for the wide voltage (V) and between nine to thirty-five volts for the wide voltage with efficient power supply module (VPT). The voltage is applied through pins one and four of the four pin *Power/Data connector*. Pins two and three are reserved for serial transmission, using either the RS-232/TTL or the I<sup>2</sup>C protocol, depending on what has been selected by the *Protocol Select Jumpers*. Pins two and three may be reversed by changing the *Legacy*

Connector Jumpers in order to be compatible with previous PCB revisions.




Figure 16: Power Connector and Pin out

Table 1: Power Requirements

	Standard	-V	-VPT
Supply Voltage	+5Vdc $\pm$ 0.25V	+9V to +15V	+9V to +35V
Backlight On	110 mA typical		
Backlight Off Supply	40 mA		



#### WARNINGS

- Do not apply any power with reversed polarization.
- Do not apply any voltage other than the specified voltage.

## 2.3 Protocol Select Jumpers

The *Protocol Select Jumpers*, pictured below in *figure 17*, provide the means necessary to toggle the display module between RS-232, TTL and I<sup>2</sup>C protocols. As a default, the jumpers are set to RS-232 mode with solder jumps on the 232 jumpers. In order to place the display module in I<sup>2</sup>C mode you must first remove the solder jumps from the 232 jumpers and then place them on the I<sup>2</sup>C jumpers. The display will now be in I<sup>2</sup>C mode and have a default slave address of 0x50 unless it has been changed. Similarly, in order to change the display to TTL mode, simply remove the zero ohm resistors from the 232 or I<sup>2</sup>C jumpers and solder them to the TTL jumpers.






Figure 17: Protocol Select Jumpers

## 2.4 General Purpose Outputs

A unique feature of the LK204-25 is the ability to control relays and other external devices using a *General Purpose Output*, which can provide up to 20 mA of current and +5Vdc from the positive side of the GPO. This is limited by a 240 ohm resistor which is located to the above right of the GPOs as pictured below in *figure 21*. If the device, which is being driven by a GPO, requires a relatively high current (such as a relay) and has an internal resistance of its own greater than 250 ohms, then the 240 ohm resistor may be removed and replaced with a Jumper.




Figure 18: General Purpose Output



**WARNING** If connecting a relay, be sure that it is fully clamped using a diode and capacitor in order to absorb any electro-motive force (EMF) which will be generated.



## 2.5 Dallas 1-Wire Bridge

In addition to the six general purpose outputs the LK204-25 offers a Dallas 1-wire bridge, to allow for an additional thirty two 1-wire devices to be connected to the display. See *Section 8.1 on page 35*.




Figure 19: Dallas 1-Wire Bridge

## 2.6 Manual Override

The *Manual Override* is provided to allow the LK204-25 to be reset to factory defaults. This can be particularly helpful if the display module has been set to an unknown baud rate or I<sup>2</sup>C Slave Address and you are no longer able to communicate with it. If you wish to return the module to its default settings you must:

1. Power off the display module.
2. Place a Jumper on the *Manual Override* pins.
3. Power up the display module.
4. The display module is now set to its default values listed below in *table 2*.
5. Edit and save settings.




Figure 20: Manual Override Jumper

Table 2: Default Values

<b>Brightness</b>	255
<b>Baud Rate</b>	19.2 kbps
<b>I<sup>2</sup>C Slave Address</b>	0x50
<b>Data Lock</b>	False
<b>RS232AutoTransmitData</b>	True

---

**NOTE** The display module will revert back to the old settings once turned off, unless the settings are saved.

---

## 2.7 Keypad Interface Connector

The LK204-25 provides a *Keypad Interface Connector* which allows for up to a five by five matrix style keypad to be directly connected to the display module. Key presses are generated when a short is detected between a row and a column. When a key press is generated a character, which is associated with the particular key press, is automatically sent on the Tx communication line. If the display module is running in I<sup>2</sup>C mode, the “Auto Transmit Keypress” function may be turned off, to allow the key presses to remain

in the buffer so that they may be polled. The character that is associated with each key press may also be altered using the “Assign Key Codes” command, for more detailed information see the *Keypad Section, on page 37*.




Figure 21: Keypad Interface Connector

---

**NOTE** The *Ground / +5V* pin is toggled by the jumper to the right of the keypad connector. Jump 1 & 2 for +5V or 2 & 3 for GND.

---

## 3 Troubleshooting

### 3.1 The display does not turn on when power is applied.

- First, you will want to make sure that you are using the correct power connector. Standard floppy drive power cables from your PC power supply may fit on the Power/Data Connector however they do not have the correct pin out as can be seen in *figure 11 on page 7*. Matrix Orbital supplies power cable adapters for connecting to a PC, which can be found in the *Accessories Section on page 2*.
- The next step is to check the power cable which you are using for continuity. If you don't have an ohm meter, try using a different power cable, if this does not help try using a different power supply.
- The last step will be to check the *Power / Data Connector* on the LK204-25. If the *Power / Data Connector* has become loose, or you are unable to resolve the issue, please contact Matrix Orbital,

see *14.5 on page 60* for contact information.

## 3.2 The display module is not communicating.

- First, check the communication cable for continuity. If you don't have an ohm meter, try using a different communication cable. If you are using a PC try using a different Com Port.
- Second, please ensure that the display module is set to communicate on the protocol that you are using, by checking the *Protocol Select Jumpers*. To change the protocol used by the display module see *Section 2.3 on page 11*.
- Third, ensure that the host system and display module are both communicating on the same baud rate. The default baud rate for the display module is 19200 bps.
- If you are communicating to the display via I<sup>2</sup>C please ensure that the data is being sent to the correct address. The default slave address for the display module is 0x50.

---

**NOTE** I<sup>2</sup>C communication will always require pull up resistors.

---

- Finally, you may reset the display to it's default settings using the *Manual Override Jumper*, see *Section 2.6 on page 13*.

## 3.3 The display module is communicating, however text cannot be displayed.

- A common cause may be that the contrast settings have been set to low. The solution to this problem is to adjust the contrast settings. The default setting that will work in most environments is 128.

---

**NOTE** Optimal contrast settings may vary according to factors such as temperature, viewing angle and lighting conditions.

If you are unable to resolve any issue please contact Matrix Orbital. See *14.5 on page 60* for contact information.

---

# 4 Communications

## 4.1 Introduction

The commands listed in this chapter describe how to configure data flow on the RS232/TTL and I<sup>2</sup>C port.

### 4.1.1 I<sup>2</sup>C Communication

The LK204-25 is capable of communicating at 400 Kbps in I<sup>2</sup>C mode, with 127 units addressable on a single I<sup>2</sup>C communication line. However, in order to communicate via I<sup>2</sup>C you must first set the Protocol

Select Jumpers as can be seen in **Section 2.3** and ensure that pull up resistors, with a nominal value of 1K to 10K, are placed on the SCL SDA communication lines coming from pins two and three of the Data / Power Connector respectively. The LK204-25 uses 8-bit addressing, with the 8th bit designated as the read write bit, a 0 designates a write address and a 1 designates a read address. The default read address of the display module will be 0x51, whereas the write address is 0x50 by default, to change the I<sup>2</sup>C address see section 8.2.1.

When communicating in I<sup>2</sup>C the LK204-25 will send an ACK on the 9th clock cycle when addressed. When writing to the display module, the display will respond with a ACK when the write has successfully been completed. However if the buffer has been filled, or the module is too busy processing data it will respond with a NAK. When performing a multiple byte read within one I<sup>2</sup>C transaction, each byte read from the slave should be followed by an ACK to indicate that the master still needs data, and a NAK to indicate that the transmission is over.

### 4.1.2 Serial Communication

In addition to being able to communicate via I<sup>2</sup>C the LK204-25 communicates natively through the RS-232 protocol at a default baud rate of 19,200 bps and is capable of standard baud rates from 1200 to 57600 bps. Furthermore the LK204-25 is also capable of reproducing any non-standard baud rate in between using values entered into our baud rate generation algorithm and set through command 164 (0xA4). The display module communicates at standard voltage levels of ±12V to ±12V or at TTL levels of 0 to +5V by setting the *Protocol Select Jumpers* to TTL.

## 4.2 Changing the I<sup>2</sup>C Slave Address

Syntax	Hexadecimal	0xFE 0x33 [adr]
	Decimal	254 51 [adr]
	ASCII	254 “3” [adr]

Parameters	Parameter	Length	Description
	adr	1	The new I <sup>2</sup> C write address (0x00 - 0xFF).

Description This command sets the I<sup>2</sup>C write address of the module between 0x00 and 0xFF. The I<sup>2</sup>C write address must be an even number and the read address is automatically set to one higher. For example if the I<sup>2</sup>C write address is set to 0x50, then the read address is 0x51.

---

**NOTE** The change in address is immediate.

---

Remembered	Always
------------	--------

Factory Default 0x50

### 4.3 Changing the Baud Rate

Syntax            Hexadecimal    0xFE 0x39 [speed]  
                      Decimal            254 57 [speed]  
                      ASCII             254 "9" [speed]

Parameters	Parameter	Length	Description
	speed	1	Hex value corresponding to a baud rate.

Description        This command sets the RS-232 port to the specified [speed]. The change takes place immediately. [speed] is a single byte specifying the desired port speed. Valid speeds are shown in the table below. The display module can be manually reset to 19,200 baud in the event of an error during transmission, including transmitting a value not listed below, by setting the manual override jumper during power up. However, it should be noted that this command will be ignored until the manual override jumper is removed again.

Hex Value	Baud Rate
53	1200
29	2400
CF	4800
67	9600
33	19200
22	28800
19	38400
10	57600

Remembered       Always

Factory Default    19,200 bps

### 4.4 Setting a Non-Standard Baud Rate

Syntax            Hexadecimal    0xFE 0xA4 [speed]  
                       Decimal            254 164 [speed]

Parameter	Parameter	Length	Description
	speed	2	Inputed LSB MSB from baud rate formula (12-2047).

Description        This command sets the RS-232 port to a non-standard baud rate. The command accepts a two byte parameter that goes directly into the modules baud generator. Use the formula,  $speed = \frac{CrystalSpeed}{8 \times DesiredBaud} - 1$  to calculate the [speed] for any baud rate setting. The speed can be anywhere from 12 to 2047 which corresponds to a baud range of 977 to 153,800 baud. Setting the baud rate out of this range could cause the display to stop working properly and require the Manual Override jumper to be set.

Remembered       Always

Examples

**Crystal Speed 8 Mhz**

$$speed = \frac{crystalspeed}{8 * DesiredBaud} - 1 \qquad speed = \frac{8,000,000}{8 * 13,500} - 1$$

$$speed = 74.07 - 1 \qquad speed = 73.07$$

- **LSB** = 0x4A (rounded)
- **MSB** = 0x00
- Inteded Baud Rate: 13,500 baud      Actual Baud Rate:  
 $\frac{8,000,000}{8(73+1)} = 13,675$       Percent Difference: 1.8%

---

**NOTES**

- Results from the formula are rounded down to the nearest whole number (73.07 = 73).
  - This formula becomes less accurate as baud rates increase, due to rounding.
  - Place the speed result backwards into the formula to receive the actual baud rate. ( $Baud = \frac{CrystalSpeed}{8(speed+1)}$ )
  - The actual baud rate must be within 3% of the intended baud rate for the device to communicate.
-

# 5 Text

## 5.1 Introduction

The LK204-25 is an intelligent display module, designed to reduce the amount of code necessary to begin displaying data. This means that it is able to display all characters and strings that are sent to it, which are defined in the current character set. The display module will begin displaying text at the top left corner of the display area, known as home, and continue to print to the display as if it was a page on a typewriter. When the text reaches the bottom right row, it is able to automatically scroll all of the lines up and continue to display text, with the auto scroll option set to on.

### 5.1.1 Character Set

		Higher 4-bit (D4 to D7) of Character Code (Hexadecimal)															
		0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
Lower 4-bit (D0 to D3) of Character Code (Hexadecimal)	0	CG RAM (1)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	1	CG RAM (2)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	2	CG RAM (3)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	3	CG RAM (4)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	4	CG RAM (5)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	5	CG RAM (6)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	6	CG RAM (7)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	7	CG RAM (8)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	8	CG RAM (1)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	9	CG RAM (2)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	A	CG RAM (3)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	B	CG RAM (4)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	C	CG RAM (5)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	D	CG RAM (6)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	E	CG RAM (7)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣
	F	CG RAM (8)	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣	␣

Figure 22: Character Set



## 5.1.2 Control Characters

**0x08** Backspace

**0x0C** Clear screen / New page

**0x0D** Carriage return

**0x0A** Line feed / New line

## 5.2 Auto Scroll On

Syntax	Hexadecimal	0xFE 0x51
	Decimal	254 81
	ASCII	254 “Q”

Description	When auto scrolling is on, it causes the display to shift the entire display’s contents up to make room for a new line of text when the text reaches the end of the last row.
-------------	---

Remembered	Yes
------------	-----

Factory Default	On
-----------------	----

## 5.3 Auto Scroll Off

Syntax	Hexadecimal	0xFE 0x52
	Decimal	254 82
	ASCII	254 “R”

Description	When auto scrolling is disabled the text will wrap to the top left corner of the display area when the text reaches the end of last row.
-------------	--

Remembered	Yes
------------	-----

## 5.4 Clear Screen

Syntax	Hexadecimal	0xFE 0x58
	Decimal	254 88
	ASCII	254 “X”
Description	This command will immediately clear all of the contents of the display.	
Remembered	No	

## 5.5 Changing the Startup Screen

Syntax	Hexadecimal	0xFE 0x40 [chars]	
	Decimal	254 64 [chars]	
	ASCII	254 “@” [chars]	
Parameters	Parameter	Length	Description
	chars	80	Characters to display for the startup screen.
Description	In order to change the text that is displayed by the LK204-25 when it starts up simply send the command bytes 254 64 followed by the characters that you wish to display, starting from the top left. This command will automatically line wrap the characters that are sent to it.		
Remembered	Yes		

## 5.6 Set Auto Line Wrap On

Syntax	Hexadecimal	0xFE 0x43
	Decimal	254 67
	ASCII	254 “C”
Description	Enabling Auto Line Wrap will allow the cursor to automatically wrap over to the next line when the current line is full.	

---

**NOTE** Line wraps may occur in the middle of a word.

---

Remembered Yes

## 5.7 Set Auto Line Wrap Off

Syntax           Hexadecimal   0xFE 0x44  
                  Decimal       254 68  
                  ASCII        254 "D"

Description      Disabling Auto Line Wrap will allow you to have full control over the cursor position. This means that once the cursor has advanced to the end of a line, it will not wrap over to the next line, unless given the 'Set Cursor Position' Command.

---

**NOTE** All characters written to the display past the end of a line will be lost.

---

Remembered Yes

## 5.8 Set Cursor Position

Syntax           Hexadecimal   0xFE 0x47 [col] [row]  
                  Decimal       254 71 [col] [row]  
                  ASCII        254 "G" [col] [row]

Parameters	Parameter	Length	Description
	col	1	Column
	row	1	Row

Description      This command will allow you to manually set the cursor position, which controls the text insertion point, by specifying the [col] and [row] of the new proposed cursor position.

---

**NOTE** If the cursor position is set past the end of a line it will wrap to the beginning of the next line.

---

Remembered No

## 5.9 Go Home

Syntax	Hexadecimal	0xFE 0x48
	Decimal	254 72
	ASCII	254 “H”
Description	This command will return the cursor to the top left corner of the display area, identified as row one, column one.	
Remembered	No	

## 5.10 Move Cursor Back

Syntax	Hexadecimal	0xFE 0x4C
	Decimal	254 76
	ASCII	254 “L”
Description	This command will move the cursor back one space. If this command is sent when the cursor is at the home position the cursor will wrap to the last row / column position if line wrap is on. Sending this command will not effect the text displayed on the module, however any characters that are sent will over write the current characters that are being displayed.	
Remembered	No	

## 5.11 Move Cursor Forward

Syntax	Hexadecimal	0xFE 0x4D
	Decimal	254 77
	ASCII	254 “M”
Description	This command will move the cursor forward one space. If this command is sent when the cursor is at the bottom right position the cursor will wrap back to the home position if line wrap is on. Sending this command will not effect the text displayed on the module, however any characters that are sent will over write the current characters that are being displayed.	
Remembered	No	

## 5.12 Underline Cursor On

Syntax	Hexadecimal	0xFE 0x4A
	Decimal	254 74
	ASCII	254 “J”
Description	This command will cause the LK204-25 to display an underline cursor at the current text insertion point.	
Remembered	Yes	

## 5.13 Underline Cursor Off

Syntax	Hexadecimal	0xFE 0x4B
	Decimal	254 75
	ASCII	254 “K”
Description	This command will turn the the underline cursor off.	
Remembered	Yes	

## 5.14 Blinking Block Cursor On

Syntax	Hexadecimal	0xFE 0x53
	Decimal	254 83
	ASCII	254 “S”
Description	This command will cause the LK204-25 to display an underline cursor at the current text insertion point.	
Remembered	Yes	

## 5.15 Blinking Block Cursor Off

Syntax	Hexadecimal	0xFE 0x54
	Decimal	254 84
	ASCII	254 “T”
Description	This command will turn the block cursor off.	
Remembered	Yes	

## 6 Special Characters

### 6.1 Introduction

### 6.2 Creating a Custom Character

Syntax	Hexadecimal	0xFE 0x4E [refID] [data]
	Decimal	254 78 [refID] [data]
	ASCII	254 “N” [refID] [data]

Parameters	Parameter	Length	Description
	refID	1	Character reference ID (0-7).
	data	8	Character data.

Description The LK204-25 allows for up to eight custom defined characters to be added onto the the character set. A custom character is a five by eight pixel matrix with each row represented by a byte value. For example:

Custom Character 'h'					Decimal	Hex
<b>1</b>	0	0	0	0	16	0x10
<b>1</b>	0	0	0	0	16	0x10
<b>1</b>	0	0	0	0	16	0x10
<b>1</b>	0	0	0	0	16	0x10
<b>1</b>	0	<b>1</b>	<b>1</b>	0	22	0x16
<b>1</b>	<b>1</b>	0	0	<b>1</b>	25	0x19
<b>1</b>	0	0	0	<b>1</b>	17	0x11
<b>1</b>	0	0	0	<b>1</b>	17	0x11

Each bit value of one, in the table, represents an on pixel, whereas a value of zero represents a pixel that is turned off. Therefore in order to define custom character 'h' you would send the command byte prefix 254 followed by the command 78. Next, you will have to select the memory location in which you wish to save the character in. The available memory locations for this command are zero through to seven. After sending the memory location, or [refID], you may then send the eight byte custom character data in sequence from the top to the bottom.

Once you have defined a custom character you may display it by sending the display module the [refID]. For example if a custom character was saved in position one, the command to display the custom character, at the current cursor position, would be simply to send the number one to the display module without quotes.

Remembered No

### 6.3 Saving Custom Characters

Syntax Hexadecimal 0xFE 0xC1 [Bank] [ID] [Data]  
 Decimal 254 193 [Bank] [ID] [Data]

Parameter	Length	Description
Bank	1	Memory bank to save to (0-4).
ID	1	Character ID (0-7)
Data	8	Character Definition

Description New to the LK204-25 has added five non-volatile memory banks for custom character storage. This is intended to allow you to create your own custom bar graphs, medium/large numbers and startup screen. However, each memory bank may be used to store a set of any eight custom characters; with the only provision being that memory bank zero contains the characters that will be used in the startup screen. By default the memory banks will be loaded as follows:

[Bank]	Description
0	Startup screen characters.
1	Horizontal bars
2	Vertical bars
3	Medium numbers
4	Large numbers

In order to save new custom characters into a memory bank, follow the same process as you would for creating a custom character, see Section 6.2 on page 26, only use 254 193 [Bank Number] before sending the [ID] and character [Data].

Remembered Yes

## 6.4 Loading Custom Characters

Syntax Hexadecimal 0xFE 0xC0 [Bank]  
 Decimal 254 192 [Bank]

Parameter	Length	Description
Bank	1	Memory bank to save to (0-4).

Description This command is used to load the custom characters into the volatile memory so that they may be used. If custom bar graph or number characters are stored in the memory banks, this command may be used instead of initializing the bar graph / number. To use this command send the command bytes followed by the [Bank] that contains the custom character data that you want to retrieve.

Remembered No

## 6.5 Save Startup Screen Custom Characters



Syntax            Hexadecimal    0xFE 0xC2 [refID] [data]  
                  Decimal            254 194 [refID] [data]

Parameters	Parameter	Length	Description
	refID	1	Character reference ID (0-7).
	data	8	Character data.

Description        Using this command you may create the custom characters. that will be stored in memory bank zero, which will be used in the startup screen. For more information about creating custom characters see **Section 6.2 on page 26**.

---

#### NOTES

- Changes only take place once the power has been cycled.
  - This command is the same as sending CMD 254 / 193 / 0 / [ID] / [DATA]
- 

Remembered        Yes

## 6.6 Initialize Medium Number

Syntax            Hexadecimal    0xFE 0x6D  
                  Decimal            254 109  
                  ASCII             254 "m"

Description        This command will load the default medium number characters into the volatile memory. If you have stored your own custom medium numbers, use the 'Load Custom Characters' command to load your custom character data into the volatile memory. This command will allow you to use the 'Place Medium Numbers' command.

Remembered        No

## 6.7 Place Medium Numbers

Syntax	Hexadecimal	0xFE 0x6F [Row] [Col] [Digit]	
	Decimal	254 111 [Row] [Col] [Digit]	
	ASCII	254 “o” [Row] [Col] [Digit]	
Parameters	<hr/>		
	Parameter	Length	Description
	Row	1	The row number.
	Col	1	The column number.
	Digit	1	Medium number to place (0-9).
Description	This command will place a medium number (two columns high) at the [row] and [col] specified.		
Remembered	No		

## 6.8 Initialize Large Numbers

Syntax	Hexadecimal	0xFE 0x6E
	Decimal	254 110
	ASCII	254 “n”
Description	This command will load the default large number characters into the volatile memory. If you have stored your own custom large numbers, use the 'Load Custom Characters' command instead to load your custom character data into the volatile memory. This command will allow you to use the 'Place Large Numbers' command.	
Remembered	No	

## 6.9 Place Large Number

Syntax	Hexadecimal	0xFE 0x23 [Col] [Digit]	
	Decimal	254 35 [Col] [Digit]	
	ASCII	254 “#” [Col] [Digit]	
Parameters	<hr/>		
	Parameter	Length	Description
	Col	1	The column number.
	Digit	1	Large number to place (0-9).

Description	This command will place a large number (four columns high) at the [row] and [col] specified.
Remembered	No

## 6.10 Initialize Horizontal Bar

Syntax	Hexadecimal 0xFE 0x68 Decimal 254 104 ASCII 254 “h”
Description	This command will load the default horizontal bar characters into the volatile memory. If you have stored your own custom horizontal bar data, use the 'Load Custom Characters' command instead to load your custom bar data into the volatile memory. This command will allow you to use the 'Place Horizontal Bar' command.
Remembered	No

## 6.11 Place Horizontal Bar Graph

Syntax	Hexadecimal 0xFE 0x7C [Col] [Row] [Dir] [Length] Decimal 254 124 [Col] [Row] [Dir] [Length] ASCII 254 “!” [Col] [Row] [Dir] [Length]															
Parameters	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Length</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Col</td> <td>1</td> <td>The column number.</td> </tr> <tr> <td>Row</td> <td>1</td> <td>The row number.</td> </tr> <tr> <td>Dir</td> <td>1</td> <td>The direction of the bar data (0 or 1).</td> </tr> <tr> <td>Length</td> <td>1</td> <td>The length of the bar data.</td> </tr> </tbody> </table>	Parameter	Length	Description	Col	1	The column number.	Row	1	The row number.	Dir	1	The direction of the bar data (0 or 1).	Length	1	The length of the bar data.
Parameter	Length	Description														
Col	1	The column number.														
Row	1	The row number.														
Dir	1	The direction of the bar data (0 or 1).														
Length	1	The length of the bar data.														
Description	This command will place a bar graph at [row], [column]. A [Dir] value of zero will cause the bar to go right, and one will cause the bar to go left. The [Length] is the size in pixels of the bar graph.															

---

**NOTE** Bar graphs may be one directional only.

---

Remembered No

## 6.12 Initialize Narrow Vertical Bar

Syntax           Hexadecimal   0xFE 0x73  
                  Decimal        254 115  
                  ASCII         254 “s”

Description      This command will load the narrow vertical bar characters into the volatile memory. If you have stored your own custom vertical bar data, use the 'Load Custom Characters' command instead to load your custom bar data into the volatile memory. This command will allow you to use the 'Place Vertical Bar' command.

---

**NOTE**   Narrow bars have a width of two pixels.

---

Remembered No

## 6.13 Initialize Wide Vertical Bar

Syntax           Hexadecimal   0xFE 0x76  
                  Decimal        254 118  
                  ASCII         254 “v”

Description      This command will load the wide vertical bar characters into the volatile memory. If you have stored your own custom vertical bar data, use the 'Load Custom Characters' command instead to load your custom bar data into the volatile memory. This command will allow you to use the 'Place Vertical Bar' command.

---

**NOTE**   Wide bars have a width of five pixels.

---

Remembered No

## 6.14 Place Vertical Bar

Syntax	Hexadecimal	0xFE 0x3D [Column] [Length]	
	Decimal	254 61 [Column] [Length]	
	ASCII	254 “=” [Column] [Length]	
Parameters	Parameter	Length	Description
	Column	1	The column number.
	Length	1	The length of the bar data.
Description	This command will place a bar graph at the specified [Column] with the specified [Length]. The [Length] is the size in pixels of the bar graph.		

---

**NOTE** Bar graphs may be one directional only.

---

Remembered No

## 7 General Purpose Output

### 7.1 Introduction

General purpose outputs allow you to connect devices, such as LEDs, to the LK204-25 and supply them with up to 20mA of current at 5V. The LK204-25 has 6 GPOs which are software controlled, with functions to turn them on/off and set the power state for the next startup.

### 7.2 General Purpose Output Off

Syntax	Hexadecimal	0xFE 0x56 [Num]	
	Decimal	254 86 [Num]	
	ASCII	254 “V” [Num]	
Parameters	Parameter	Length	Description
	Num	1	GPO number.

Description This command turns OFF general purpose output [num].

---

**NOTE** OFF means that the output is ground.

---

Remembered Yes

### 7.3 General Purpose Output On

Syntax Hexadecimal 0xFE 0x57 [Num]  
Decimal 254 87 [Num]  
ASCII 254 "W" [Num]

Parameter	Length	Description
Num	1	GPO number.

Description This command turns ON general purpose output [num]. The standard GPO's on the LK204-25 output 20mA of current at 5V.

---

**NOTE** The output is pulled high.

---

Remembered Yes

### 7.4 Set Startup GPO state

Syntax Hexadecimal 0xFE 0xC3 [Num] [state]  
Decimal 254 195 [Num] [state]

Parameter	Length	Description
Num	1	GPO number.
state	1	Startup state (0: Off, 1: On)

Description This command will set the startup state for the GPO on the next power up. A value of one will cause the GPO to be off on the next startup while a value of zero will cause the GPO to be on.

---

**NOTE** This command does not affect the current state of the GPO.

---

Remembered Always

## 8 Dallas 1-Wire

### 8.1 Introduction

Another convenient feature of the LK204-25 is that it provides a Dallas 1-wire interface in order to readily communicate with up to thirty two 1-wire devices on a single bus. 1-wire communication is begun by discovering the address of the device that you wish to communicate with. To do this you must send the "Search for a 1-Wire Device" command. After you have established the address of the device that you wish to communicate with, you may begin a transaction with the device

### 8.2 Search for a 1-Wire Device

Syntax Hexadecimal 0xFE 0xC8 0x2  
Decimal 254 200 2

Description This command will allow you to begin communicating with the devices on the 1-wire bus by returning a packet containing device information for each 1-wire device on the bus in the form of:

#### Search Return Packet

Offset (Bytes)	Offset (Bytes)	Description
0	2	<b>0x232A</b> Preamble
2	1	<b>0x8A</b> Packet is 10 bytes long, another address will follow <b>0x0A</b> Packet is 10 bytes long, this is the last address
3	1	0x31 - 1-Wire Packet Type
4	1	Error Code (0x00 for success)
5	8	1-Wire Address
13	1	<b>CRC8</b> 0x00 means the last address was valid

Remembered No

## 8.3 Dallas 1-Wire Transaction

Syntax Hexadecimal 0xFE 0xC8 0x1 [flags] [SndBits] [RcvBits] [Data]  
 Decimal 254 200 1 [flags] [SndBits] [RcvBits] [Data]



Parameter	Parameter	Length	Description
	flags	1	Flags to control optional components of the transaction.
	SndBits	1	The number of bits you will be transmitting on the bus.
	RcvBits	1	The number of bits you will be reading on the bus.
	Data	variable	Data to be transmitted, LSB to MSB.

**Description** This command will perform a single transaction on the 1-wire bus in this order:

1. Bus Reset.
2. Transmit data onto the bus.
3. Receive data from the bus.

The number of bits to be transmitted and read must be specified for this command to be successful.

---

**NOTE** To determine what functions the device will respond to, consult the devices' data sheet.

---

#### 1-Wire Flags

Bit	Description
7	
6	Unused
5	(0 for future compatibility)
4	
3	Add a CRC8 to the end of the transmitted data
2	(0 for future compatibility)
1	Assume last received byte is a CRC8 and validate it
0	Reset bus before transaction

#### 1-Wire Error Codes

Code	Description
0x00	Success
0x01	Unknown 1-Wire Command
0x02	No devices on the bus
0x03	Fatal search error

Remembered No

## 9 Keypad

### 9.1 Introduction

The LK204-25 supports up to a 25 key, matrix style, keypad and may be configured to allow key presses to be automatically transmitted via RS-232 or polled through I<sup>2</sup>C. The LK204-25 also allows for auto-repeating key presses, and remapping of all keypad character codes.

### 9.2 Auto Transmit Key Presses On

Syntax	Hexadecimal	0xFE 0x41
	Decimal	254 65
	ASCII	254 "A"
Description	In this mode, all key presses are sent immediately to the host system without the use of the poll keypad command. This is the default mode on power up.	
Remembered	Yes	
Factory Default	On	

### 9.3 Auto Transmit Key Presses Off

Syntax	Hexadecimal	0xFE 0x4F
	Decimal	254 79
	ASCII	254 "O"
Description	In this mode, up to 10 key presses are buffered until the unit is polled by the host system, via the poll keypad command 254 38. Issuing this command places the unit in polled mode.	
Remembered	Yes	

### 9.4 Poll Key Press

Syntax	Hexadecimal	0xFE 0x26
	Decimal	254 38
	ASCII	254 “&”
Description	This command returns any buffered key presses via the RS-232 interface. The host system must be set up to receive key codes. When the display receives this command, it will immediately return any buffered key presses which may have not been read already. If there is more than one key press buffered, then the high order bit (MSB) of the returned key code will be set (1). If this is the only buffered key press, then the MSB will be cleared (0). If there are no buffered key presses, then the returned code will be 0x00. Please note that to make use of this command, the “Auto Transmit Key Presses” mode should be off.	
Remembered	No	

## 9.5 Clear Key Buffer

Syntax	Hexadecimal	0xFE 0x45
	Decimal	254 69
	ASCII	254 “E”
Description	This command clears any unread key presses. In a menu application, if the user presses a key which changes the menu context, any following key presses may be inaccurate and can be cleared out of the buffer between menu changes to prevent jumping around the menu tree. It may also be used, in effect, to reset the keypad in case the host application resets for whatever reason.	
Remembered	No	

## 9.6 Set Debounce Time

Syntax	Hexadecimal	0xFE 0x55 [time]
	Decimal	254 85 [time]
	ASCII	254 “U” [time]

Parameters	Parameter	Length	Description
	time	1	Debounce time in increments of 6.554ms (0 - 255).
Description	This command sets the time between key press and key read. All key types with the exception of latched piezo switches will 'bounce' for a varying time, depending on their physical characteristics. The [time] value is in increments of 6.554ms. The default debounce time for the module is 8 (about 52ms), which is adequate for most membrane key-pads.		
Remembered	Yes		
Factory Default	8		

## 9.7 Set Auto Repeat Mode

Syntax	Hexadecimal	0xFE 0x7E [mode]	
	Decimal	254 126 [mode]	
	ASCII	254 "~" [mode]	
Parameters	Parameter	Length	Description
	mode	1	Auto Repeat Mode (0: Resend Key , 1: Key Up/Down)

Description	<p>Two auto repeat modes are available and are set via the same command:</p> <ul style="list-style-type: none"> <li>• <b>Resend Key Mode:</b> 0x00</li> <li>• <b>Key Up/Down Mode:</b> 0x01</li> </ul> <p><b>Resend Key Mode</b> This mode is similar to the action of a keyboard on a PC. In this mode, when a key is held down, the key code is transmitted immediately followed by a 1/2 second delay. After this delay, key codes will be sent via the RS-232 interface at a rate of about 5 codes per second. This mode has no effect if polling or if using the I<sup>2</sup>C interface.</p> <p><b>Key Up/Down Mode</b> This mode may be used when the typematic parameters of the “Resend Key Code” mode are unacceptable or if the unit is being operated in polled mode. The host system detects the press of a key and simulates an auto repeat inside the host system until the key release is detected. In this mode, when a key is held down, the key code is transmitted immediately and no other codes will be sent until the key is released. On the release of the key, the key release code transmitted will be a value equal to the key down code plus 20 hex.</p>
Remembered	Yes
Examples	<p>When the key code associated with key 'P' (0x50) is pressed, the release code is 'p' (0x70). In RS-232 polled mode or via the I<sup>2</sup>C, the “Key Down / Key Up” codes are used; however, the user should be careful of timing details. If the poll rate is slower than the simulated auto-repeat it is possible that polling for a key up code will be delayed long enough for an unwanted key repeat to be generated.</p>

## 9.8 Auto Repeat Mode Off

Syntax	<p>Hexadecimal 0xFE 0x60</p> <p>Decimal 254 96</p> <p>ASCII 254 “”</p>
Description	This command turns auto repeat mode off. See Set Auto Repeat Mode.
Remembered	No

## 9.9 Assign Keypad Codes

Syntax                   Hexadecimal   0xFE 0xD5 [KDown] [KUp]  
                          Decimal       254 213 [KDown] [KUp]

Parameters	Parameter	Length	Description
	KDown	25	Key down codes
	KUp	25	Key up codes

Description           This command will allow you to reassign the key codes that correspond to the key presses on the matrix style key pad. The first 25 bytes that are transmitted will be used for the key down codes and the next 25 bytes that are transmitted will be used for the key up codes. The default values of the key down codes are 'A-Y' in order, and for the key up codes the values are 'a-y' in order.

Key Down						Key Up					
	1	2	3	4	5		1	2	3	4	5
1	A	B	C	D	E	1	a	b	c	d	e
2	F	G	H	I	J	2	f	g	h	i	j
3	K	L	M	N	O	3	k	l	m	n	o
4	P	Q	R	S	T	4	p	q	r	s	t
5	U	V	W	X	Y	5	u	v	w	x	y

Remembered           Always

## 10 Display Functions

### 10.1 Introduction

The LK204-25 employs software controlled display settings, which allow for control over, clearing the screen, changing the brightness and contrast or setting timers for turning it on or off. The combination of these allow you complete software control over your display's appearance.

### 10.2 Display On

Syntax	Hexadecimal	0xFE 0x42 [min]						
	Decimal	254 66 [min]						
	ASCII	254 “B” [min]						
Parameters	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Length</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>min</td> <td>1</td> <td>Minutes before turning the display on (0 to 100).</td> </tr> </tbody> </table>		Parameter	Length	Description	min	1	Minutes before turning the display on (0 to 100).
Parameter	Length	Description						
min	1	Minutes before turning the display on (0 to 100).						
Description	This command turns the display on after the [minutes] timer has expired , with a one-hundred minute maximum timer. A time of 0 specifies that the display should turn on immediately and stay on. When this command is sent while the remember function is on, the timer will reset and begin after power up.							
Remembered	Yes							
Factory Default	0							

### 10.3 Display Off

Syntax	Hexadecimal	0xFE 0x46
	Decimal	254 70
	ASCII	254 “F”
Description	This command turns the display off immediately. The display will remain off until a ‘Display On’ command has been received.	
Remembered	Yes	

### 10.4 Set Brightness

Syntax	Hexadecimal	0xFE 0x99 [brightness]						
	Decimal	254 153 [brightness]						
Parameters	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Length</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>brightness</td> <td>1</td> <td>Display brightness setting (0 to 255).</td> </tr> </tbody> </table>		Parameter	Length	Description	brightness	1	Display brightness setting (0 to 255).
Parameter	Length	Description						
brightness	1	Display brightness setting (0 to 255).						

Description	This command sets the display [brightness]. If the remember function is on, this command acts the same as 'Set and Save Brightness'.
Remembered	Yes
Factory Default	255

## 10.5 Set and Save Brightness

Syntax	Hexadecimal	0xFE 0x98 [brightness]						
	Decimal	254 152 [brightness]						
Parameters	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Length</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>brightness</td> <td>1</td> <td>Backlight setting (0 to 255).</td> </tr> </tbody> </table>		Parameter	Length	Description	brightness	1	Backlight setting (0 to 255).
Parameter	Length	Description						
brightness	1	Backlight setting (0 to 255).						
Description	This command sets and saves the display [brightness] as default.							
Remembered	Always							

## 10.6 Set Contrast

Syntax	Hexadecimal	0xFE 0x50 [contrast]						
	Decimal	254 80 [contrast]						
	ASCII	254 "P" [contrast]						
Parameters	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Length</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>contrast</td> <td>1</td> <td>Contrast value (0 to 255).</td> </tr> </tbody> </table>		Parameter	Length	Description	contrast	1	Contrast value (0 to 255).
Parameter	Length	Description						
contrast	1	Contrast value (0 to 255).						



Description	<p>This command sets the display's contrast to [contrast], where [contrast] is a value between 0x00 and 0xFF (between 0 to 255). Lower values cause 'on' elements in the display area to appear lighter, while higher values cause 'on' elements to appear darker. Lighting and temperature conditions will affect the actual value used for optimal viewing. Individual display modules will also differ slightly from each other in appearance. In addition, values for optimal viewing while the display backlight is on may differ from values used when backlight is off.</p> <p>This command does not save the [contrast] value, and is lost after power down; but this command has the option of remembering the settings when issued with the Remember function 'on' . When this is the case, this command is the same as the Set and Save Contrast command.</p>
Remembered	Yes
Factory Default	128

## 10.7 Set and Save Contrast

Syntax	Hexadecimal	0xFE 0x91 [contrast]
	Decimal	254 145 [contrast]

Parameters	Parameter	Length	Description
	contrast	1	Contrast value (0 to 255).

Description	<p>This command sets the display's contrast to [contrast], where [contrast] is a value between 0x00 and 0xFF (between 0 to 255). Lower values cause 'on' elements in the display area to appear lighter, while higher values cause 'on' elements to appear darker. Lighting conditions will affect the actual value used for optimal viewing. Individual display modules will also differ slightly from each other in appearance. In addition, values for optimal viewing while the display backlight is on may differ from values used when backlight is off.</p>
-------------	--

---

**NOTE** This command saves the [contrast] value so that it is not lost after power down.

---

Remembered	Yes
------------	-----

# 11 Data Security

## 11.1 Introduction

Ensuring that your LK204-25 display's exactly what you want it to can be the difference between a projects success and failure. This is why we incorporate features such as Data Lock into the LK204-25 With this new feature you now are in control over of how and when settings will be changed so there is no need to worry about the module acting exactly like you expected it to because all the settings may be locked and remembered for the next power up.

## 11.2 Set Remember

Syntax                      Hexadecimal    0xFE 0x93 [switch]  
                                   Decimal            254 147 [switch]

Parameters	Parameter	Length	Description
	switch	1	0: Do not remember, 1: Remember

Description This command allows you to switch the remember function on and off. To use the remember function, set remember to on, then set all of the settings that you wish to save, settings that are listed as 'Remember: Yes' support being saved into the non-volatile memory. After you have set all of the commands that you wish to save, you may then cycle the power and check the display settings to ensure that all the settings have been saved. If you wish to use remember again after cycling the power, you must set it to on again.

---

#### NOTES

- Writing to non-volatile memory is time consuming and slows down the operation of the display.
  - Non-volatile memory has a 'write limit' and may only be changed approximately 100,000 times.
- 

Remembered No

Factory Default Do not remember

### 11.3 Data Lock

Syntax Hexadecimal 0xFE 0xCA 0xF5 0xA0 [level]  
Decimal 254 202 245 160 [level]

Parameters	Parameter	Length	Description
	level	1	Sets the data lock level

Description

Data lock, originally known as paranoia, allows you to lock the module from displaying information, as well as enables the protection of the filesystem and module settings. Each bit corresponds to a different lock level, while sending a zero will unlock your display as the following tables explains:

Bit	Data Lock Level	Description
0	Unlock	Sending a zero will cause the display to unlock. (0)
1-4	Reserved	These bits are used as place holders and should not be omitted. (0000)
5	Setting Lock	Locks the display settings such as backlight, contrast and GPO settings. (10000)
6	Reserved for graphical displays. (000000)	
7	Command Lock	Locks all commands but the data lock command. (1000000)
8	Display Lock	Locks the module from displaying any new information. (10000000)

---

**NOTES**

- Sending a new data lock level will override the previous data lock level.
  - Data lock levels may be combined.
- 

Remembered Always

Factory Default 0

Examples

Hex	Dec	Binary	Description
0x00	0	0	Unlock
0x50	80	01010000	Setting and Command Lock

## 11.4 Set and Save Data Lock

Syntax	Hexadecimal	0xFE 0xCB 0xF5 0xA0 [level]						
	Decimal	254 203 245 160 [level]						
Parameters	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Length</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>level</td> <td>1</td> <td>Sets the data lock level</td> </tr> </tbody> </table>		Parameter	Length	Description	level	1	Sets the data lock level
Parameter	Length	Description						
level	1	Sets the data lock level						
Description	This command will set and save the data lock level. See the Data Lock section for more information.							
Remembered	Always							
Factory Default	0							

## 12 Miscellaneous

### 12.1 Introduction

This chapter covers the 'Report Version Number' and 'Read Module Type' commands. These commands can be particularly useful to find out more information about the display module before contacting technical support.

### 12.2 Read Version Number

Syntax	Hexadecimal	0xFE 0x36
	Decimal	254 54
	ASCII	254 "6"
Description	This command will return a byte representing the version of the module, see the following table as an example:	

Hex Value	Version Number
0x10	Version 1.0
0x20	Version 2.0
0x42	Version 4.2

Remembered	No
------------	----

## 12.3 Read Module Type

Syntax                   Hexadecimal   0xFE 0x37  
                          Decimal        254 55  
                          ASCII         254 “7”

Description            This command will return a hex value corresponding to the the model number of the module see the following table:

Hex	Product ID	Hex	Product ID
<b>1</b>	LCD0821	<b>36</b>	LK202-24-USB
<b>2</b>	LCD2021	<b>37</b>	VK202-24-USB
<b>5</b>	VK202-25	<b>38</b>	LK204-24-USB
<b>6</b>	LCD4021	<b>39</b>	VK204-24-USB
<b>7</b>	LCD4041	<b>3A</b>	PK162-12
<b>8</b>	LK202-25	<b>3B</b>	VK162-12
<b>9</b>	LK204-25	<b>3C</b>	MOS-AP-162A
<b>A</b>	LK404-55	<b>3D</b>	PK202-25
<b>B</b>	VFD2021	<b>3E</b>	MOS-AL-162A
<b>C</b>	VFD2041	<b>40</b>	MOS-AV-202A
<b>D</b>	VFD4021	<b>41</b>	MOS-AP-202A
<b>E</b>	VK202-25	<b>42</b>	PK202-24-USB
<b>F</b>	VK204-25	<b>43</b>	MOS-AL-082
<b>10</b>	GLC12232	<b>44</b>	MOS-AL-204
<b>13</b>	GLC24064	<b>45</b>	MOS-AV-204
<b>15</b>	GLK24064-25	<b>46</b>	MOS-AL-402
<b>22</b>	GLK12232-25-WBL	<b>47</b>	MOS-AV-402
<b>24</b>	GLK12232-25-SM	<b>48</b>	LK082-12
<b>31</b>	LK404-AT	<b>49</b>	VK402-12
<b>32</b>	MOS-AV-162A	<b>4A</b>	VK404-55
<b>33</b>	LK402-12	<b>4B</b>	LK402-25
<b>34</b>	LK162-12	<b>4C</b>	VK402-25
<b>35</b>	LK204-25PC		

Remembered            No

## 13 Command Summary

### 13.1 Communications

Description	Syntax	Page
Changing the I <sup>2</sup> C Slave Address	Hexadecimal	0xFE 0x33 [adr]
	Decimal	254 51 [adr]
	ASCII	254 “3” [adr]
Changing the Baud Rate	Hexadecimal	0xFE 0x39 [speed]
	Decimal	254 57 [speed]
	ASCII	254 “9” [speed]
Setting a Non-Standard Baud Rate	Hexadecimal	0xFE 0xA4 [speed]
	Decimal	254 164 [speed]

## 13.2 Text

Description	Syntax	Page
Auto Scroll On	Hexadecimal	0xFE 0x51
	Decimal	254 81
	ASCII	254 “Q”
Auto Scroll Off	Hexadecimal	0xFE 0x52
	Decimal	254 82
	ASCII	254 “R”
Clear Screen	Hexadecimal	0xFE 0x58
	Decimal	254 88
	ASCII	254 “X”
Changing the Startup Screen	Hexadecimal	0xFE 0x40 [chars]
	Decimal	254 64 [chars]
	ASCII	254 “@” [chars]
Set Auto Line Wrap On	Hexadecimal	0xFE 0x43
	Decimal	254 67
	ASCII	254 “C”
Set Auto Line Wrap Off	Hexadecimal	0xFE 0x44
	Decimal	254 68
	ASCII	254 “D”
Set Cursor Position	Hexadecimal	0xFE 0x47 [col] [row]
	Decimal	254 71 [col] [row]
	ASCII	254 “G” [col] [row]

Description	Syntax	Page
Go Home	Hexadecimal	0xFE 0x48
	Decimal	254 72
	ASCII	254 "H"
Move Cursor Back	Hexadecimal	0xFE 0x4C
	Decimal	254 76
	ASCII	254 "L"
Move Cursor Forward	Hexadecimal	0xFE 0x4D
	Decimal	254 77
	ASCII	254 "M"
Underline Cursor On	Hexadecimal	0xFE 0x4A
	Decimal	254 74
	ASCII	254 "J"
Underline Cursor Off	Hexadecimal	0xFE 0x4B
	Decimal	254 75
	ASCII	254 "K"
Blinking Block Cursor On	Hexadecimal	0xFE 0x53
	Decimal	254 83
	ASCII	254 "S"
Blinking Block Cursor Off	Hexadecimal	0xFE 0x54
	Decimal	254 84
	ASCII	254 "T"

### 13.3 Special Characters

Description	Syntax	Page
Creating a Custom Character	Hexadecimal	0xFE 0x4E [refID] [data]
	Decimal	254 78 [refID] [data]
	ASCII	254 "N" [refID] [data]
Saving Custom Characters	Hexadecimal	0xFE 0xC1 [Bank] [ID] [Data]
	Decimal	254 193 [Bank] [ID] [Data]
Loading Custom Characters	Hexadecimal	0xFE 0xC0 [Bank]
	Decimal	254 192 [Bank]



Description	Syntax	Page
Save Startup Screen Custom Characters	Hexadecimal 0xFE 0xC2 [refID] [data] Decimal 254 194 [refID] [data]	28
Initialize Medium Number	Hexadecimal 0xFE 0x6D Decimal 254 109 ASCII 254 "m"	29
Place Medium Numbers	Hexadecimal 0xFE 0x6F [Row] [Col] [Digit] Decimal 254 111 [Row] [Col] [Digit] ASCII 254 "o" [Row] [Col] [Digit]	29
Initialize Large Numbers	Hexadecimal 0xFE 0x6E Decimal 254 110 ASCII 254 "n"	30
Place Large Number	Hexadecimal 0xFE 0x23 [Col] [Digit] Decimal 254 35 [Col] [Digit] ASCII 254 "#" [Col] [Digit]	30
Initialize Horizontal Bar	Hexadecimal 0xFE 0x68 Decimal 254 104 ASCII 254 "h"	31
Place Horizontal Bar Graph	Hexadecimal 0xFE 0x7C [Col] [Row] [Dir] [Length] Decimal 254 124 [Col] [Row] [Dir] [Length] ASCII 254 "l" [Col] [Row] [Dir] [Length]	31
Initialize Narrow Vertical Bar	Hexadecimal 0xFE 0x73 Decimal 254 115 ASCII 254 "s"	32
Initialize Wide Vertical Bar	Hexadecimal 0xFE 0x76 Decimal 254 118 ASCII 254 "v"	32
Place Vertical Bar	Hexadecimal 0xFE 0x3D [Column] [Length] Decimal 254 61 [Column] [Length] ASCII 254 "=" [Column] [Length]	32

## 13.4 General Purpose Output

Description	Syntax	Page
General Purpose Output Off	Hexadecimal	0xFE 0x56 [Num]
	Decimal	254 86 [Num]
	ASCII	254 “V” [Num]
General Purpose Output On	Hexadecimal	0xFE 0x57 [Num]
	Decimal	254 87 [Num]
	ASCII	254 “W” [Num]
Set Startup GPO state	Hexadecimal	0xFE 0xC3 [Num] [state]
	Decimal	254 195 [Num] [state]

## 13.5 Dallas 1-Wire

Description	Syntax	Page
Search for a 1-Wire Device	Hexadecimal	0xFE 0xC8 0x2
	Decimal	254 200 2
Dallas 1-Wire Transaction	Hexadecimal	0xFE 0xC8 0x1 [flags] [SndBits] [RcvBits] [Data]
	Decimal	254 200 1 [flags] [SndBits] [RcvBits] [Data]

## 13.6 Keypad

Description	Syntax	Page
Auto Transmit Key Presses On	Hexadecimal	0xFE 0x41
	Decimal	254 65
	ASCII	254 “A”
Auto Transmit Key Presses Off	Hexadecimal	0xFE 0x4F
	Decimal	254 79
	ASCII	254 “O”
Poll Key Press	Hexadecimal	0xFE 0x26
	Decimal	254 38
	ASCII	254 “&”
Clear Key Buffer	Hexadecimal	0xFE 0x45
	Decimal	254 69
	ASCII	254 “E”

Description	Syntax	Page	
Set Debounce Time	Hexadecimal	0xFE 0x55 [time]	39
	Decimal	254 85 [time]	
	ASCII	254 “U” [time]	
Set Auto Repeat Mode	Hexadecimal	0xFE 0x7E [mode]	40
	Decimal	254 126 [mode]	
	ASCII	254 “~” [mode]	
Auto Repeat Mode Off	Hexadecimal	0xFE 0x60	41
	Decimal	254 96	
	ASCII	254 “”	
Assign Keypad Codes	Hexadecimal	0xFE 0xD5 [KDown] [KUp]	41
	Decimal	254 213 [KDown] [KUp]	

## 13.7 Display Functions

Description	Syntax	Page	
Display On	Hexadecimal	0xFE 0x42 [min]	42
	Decimal	254 66 [min]	
	ASCII	254 “B” [min]	
Display Off	Hexadecimal	0xFE 0x46	43
	Decimal	254 70	
	ASCII	254 “F”	
Set Brightness	Hexadecimal	0xFE 0x99 [brightness]	43
	Decimal	254 153 [brightness]	
Set and Save Brightness	Hexadecimal	0xFE 0x98 [brightness]	43
	Decimal	254 152 [brightness]	
Set Contrast	Hexadecimal	0xFE 0x50 [contrast]	44
	Decimal	254 80 [contrast]	
	ASCII	254 “P” [contrast]	
Set and Save Contrast	Hexadecimal	0xFE 0x91 [contrast]	44
	Decimal	254 145 [contrast]	

## 13.8 Data Security

Description	Syntax	Page	
Set Remember	Hexadecimal	0xFE 0x93 [switch]	45
	Decimal	254 147 [switch]	
Data Lock	Hexadecimal	0xFE 0xCA 0xF5 0xA0 [level]	46
	Decimal	254 202 245 160 [level]	
Set and Save Data Lock	Hexadecimal	0xFE 0xCB 0xF5 0xA0 [level]	47
	Decimal	254 203 245 160 [level]	

## 13.9 Miscellaneous

Description	Syntax	Page	
Read Version Number	Hexadecimal	0xFE 0x36	48
	Decimal	254 54	
	ASCII	254 “6”	
Read Module Type	Hexadecimal	0xFE 0x37	49
	Decimal	254 55	
	ASCII	254 “7”	

## 13.10 Command By Number

Command			Description	Page
Hex	Dec	ASCII		
0x23	35	“#”	Place Large Number	30
0x26	38	“&”	Poll Key Press	38
0x33	51	“3”	Changing the I <sup>2</sup> C Slave Address	17
0x36	54	“6”	Read Version Number	48
0x37	55	“7”	Read Module Type	49
0x39	57	“9”	Changing the Baud Rate	18
0x3D	61	“=”	Place Vertical Bar	32
0x40	64	“@”	Changing the Startup Screen	22
0x41	65	“A”	Auto Transmit Key Presses On	38
0x42	66	“B”	Display On	42
0x43	67	“C”	Set Auto Line Wrap On	22
0x44	68	“D”	Set Auto Line Wrap Off	23

Command		ASCII	Description	Page
Hex	Dec			
0x45	69	“E”	Clear Key Buffer	39
0x46	70	“F”	Display Off	43
0x47	71	“G”	Set Cursor Position	23
0x48	72	“H”	Go Home	24
0x4A	74	“J”	Underline Cursor On	25
0x4B	75	“K”	Underline Cursor Off	25
0x4C	76	“L”	Move Cursor Back	24
0x4D	77	“M”	Move Cursor Forward	24
0x4E	78	“N”	Creating a Custom Character	26
0x4F	79	“O”	Auto Transmit Key Presses Off	38
0x50	80	“P”	Set Contrast	44
0x51	81	“Q”	Auto Scroll On	21
0x52	82	“R”	Auto Scroll Off	21
0x53	83	“S”	Blinking Block Cursor On	25
0x54	84	“T”	Blinking Block Cursor Off	25
0x55	85	“U”	Set Debounce Time	39
0x56	86	“V”	General Purpose Output Off	33
0x57	87	“W”	General Purpose Output On	34
0x58	88	“X”	Clear Screen	21
0x60	96	“”	Auto Repeat Mode Off	41
0x68	104	“h”	Initialize Horizontal Bar	31
0x6D	109	“m”	Initialize Medium Number	29
0x6E	110	“n”	Initialize Large Numbers	30
0x6F	111	“o”	Place Medium Numbers	29
0x73	115	“s”	Initialize Narrow Vertical Bar	32
0x76	118	“v”	Initialize Wide Vertical Bar	32
0x7C	124	“l”	Place Horizontal Bar Graph	31
0x7E	126	“~”	Set Auto Repeat Mode	40
0x91	145		Set and Save Contrast	44
0x93	147		Set Remember	45
0x98	152		Set and Save Brightness	43
0x99	153		Set Brightness	43
0xA4	164		Setting a Non-Standard Baud Rate	18
0xC0	192		Loading Custom Characters	28
0xC1	193		Saving Custom Characters	27
0xC2	194		Save Startup Screen Custom Characters	28
0xC3	195		Set Startup GPO state	34
0xC8	200		Dallas 1-Wire Transaction	36
0xCA	202		Data Lock	46

# 14 Appendix

## 14.1 Specifications

### 14.1.1 Environmental

Table 67: Environmental Specifications

	<b>Standard Temperature</b>	<b>Extended Temperature</b>
<b>Operating Temperature</b>	0°C to +50°C	-20°C to +70°C
<b>Storage Temperature</b>	-20°C to +70°C	-30°C to +80°C
<b>Operating Relative Humidity</b>	90% max non-condensing	
<b>Vibration (Operating)</b>	4.9 m/s <sup>2</sup> XYZ directions	
<b>Vibration (Non-Operating)</b>	19.6 m/s <sup>2</sup> XYZ directions	
<b>Shock (Operating)</b>	29.4 m/s <sup>2</sup> XYZ directions	
<b>Shock (Non-Operating)</b>	490 m/s <sup>2</sup> XYZ directions	

### 14.1.2 Electrical

Table 68: Electrical Specifications

	<b>Standard</b>	<b>Wide Voltage (V)</b>	<b>Wide Voltage with Efficient Switching Power Supply (VPT)</b>
<b>Supply Voltage</b>	+5Vdc ±0.25V	+9V to +15V	+9V to +35V
<b>Backlight On</b>	110 mA typical		
<b>Backlight Off Supply</b>	40 mA		


## 14.2 Optical Characteristics

Table 69: Optical Characteristics

<b>Character x Lines</b>	20 columns x 2 rows
<b>Module Size</b>	98.00 mm x 60.00 mm x 30.63 mm
<b>Character Size</b>	3.20 mm x 5.55 mm
<b>Display Size</b>	76.30 mm x 25.00 mm
<b>LED Backlight Life</b>	100, 000 hours typical

# 14.3 Physical Layout

Figure 23: Physical Diagram





## 14.4 Definitions

**E** Extended Temperature (-20C to 70C)

**VPT** Wide Voltage with Efficient Switching Power Supply (+9 to +35Vdc)

**V** Wide Voltage (+9 to +15Vdc)

**GW** Grey Text / White Background

**WB** White Text / Blue Background

**R** Inverse Red

**IY** Inverse Yellow

**MSB** Most Significant Byte

**LSB** Least Significant Byte

## 14.5 Contacting Matrix Orbital

### Telephone

Sales and Support: 1(403)229-2737

### On The Web

Sales: <http://www.MatrixOrbital.com>

Support: <http://www.MatrixOrbital.ca>

Forums: <http://www.lcdforums.com>